

TOYOTA 2R				
PART #	O.E #	KIT ITEMS	KIT ITEMS	DESCRIPTION
RLBTY/2R				Rebuilt Long Block
RCHTY/2R				Rebuilt Cylinder Head
002R00				Complete Kit
002R10				Basic Kit
012R-00		CK	BK	Piston Std
012R-02		CK	BK	Piston .50mm
012R-03		CK	BK	Piston .75mm
012R-04		CK	BK	Piston 1.00mm
012R-06		CK	BK	Piston 1.50mm
022R-00		CK	BK	Ring Set Std
022R-02		CK	BK	Ring Set .50mm
022R-03		CK	BK	Ring Set .75mm
022R-04		CK	BK	Ring Set 1.00mm
022R-06		CK	BK	Ring Set 1.50mm
032R-00		CK	BK	Main Brg Set Std
032R-01		CK	BK	Main Brg Set .25mm
032R-02		CK	BK	Main Brg Set .50mm
032R-03		CK	BK	Main Brg Set .75mm
032R-04		CK	BK	Main Brg Set 1.00mm
042R-00		CK	BK	Rod Brg Set Std
042R-01		CK	BK	Rod Brg Set .25mm
042R-02		CK	BK	Rod Brg Set .50mm
042R-03		CK	BK	Rod Brg Set .75mm
042R-04		CK	BK	Rod Brg Set 1.00mm
052R00		CK	BK	Cam Brg Set
062R00		CK	BK	Thrust Washer Set
072R00		CK	BK	Pin Bushing Set
082R01		CK	BK	O/H Gasket Set (Square)
082R02		CK	BK	O/H Gasket Set (Round)
092R00				Liner
102R00		CK		Oil Pump
112R10		CK		Intake Valve (Square)
112R20		CK		Intake Valve (Round)
122R10		CK		Exhaust Valve (Square)
122R20		CK		Exhaust Valve (Round)
132R00		CK		Valve Guide
162R00				Valve Stem Seal
412R00		CK	BK	Freeze Plug Kit